



盟

Appendix 4 CIC BIM User Guide for Preparation of Statutory Plan Submissions

Tekla

December 2020

0

TIME

Disclaimer

Whilst reasonable efforts have been made to ensure the accuracy of the information contained in this publication (Reference Materials), the CIC nevertheless encourages readers to seek appropriate independent advice from their professional advisers where possible. Readers should not treat or rely on this publication (Reference Materials) as a substitute for such professional advice.

Enquiries

Enquiries about this Reference Materials may be made to the CIC Secretariat at: 38/F, COS Centre 56 Tsun Yip Street, Kwun Tong, Kowloon Hong Kong

> Tel: (852) 2100 9000 Fax: (852) 2100 9090 Email: <u>bim@cic.hk</u> Website: <u>www.cic.hk</u>

© 2020 Construction Industry Council.

Copyright Notice

This Reference Materials will only become truly useful if as many organisations adopt it as possible. To that extent, it may be freely distributed and used in any format necessary, provided credit is given to the CIC.

Contents

| Har | dware / System Requirements | 1 |
|------|--|--|
| 1.1 | General | 1 |
| Tek | la Basics | 2 |
| 2.1 | User Interface | 2 |
| 2.2 | Project base point, Grid, Levels and Work Planes | 2 |
| 2.3 | Parts and Components | 2 |
| 2.4 | Catalogs and Define Profiles | 3 |
| 2.5 | Phases, View Filter and Organiser | 3 |
| 2.6 | Suggested Model Nesting Method, Reference Models and Model Sharing | 3 |
| 2.7 | Views and Drawings | 4 |
| 2.8 | Annotation and Dimensioning | 4 |
| 2.9 | Template Editor, Tables and Drawing Layout | 4 |
| 2.10 | 2D Library and Symbol Editor | 5 |
| 2.11 | User Define Attributes | 5 |
| Get | ting Start | 6 |
| 3.1 | Opening Project Template | 6 |
| 3.2 | Set-up of Project Base Points | 6 |
| 3.3 | Creating Grids | 7 |
| Crea | ating Model Objects | 8 |
| 4.1 | Creating Slabs | 9 |
| 4.2 | Creating Columns | . 10 |
| 4.3 | Creating Panels (Walls) | . 11 |
| 4.4 | Creating Beams | . 12 |
| 4.5 | Creating Slab Openings | . 13 |
| 4.6 | Creating a Staircase | . 13 |
| 4.7 | Creating Piles | . 14 |
| 4.8 | Creating Pile Caps and Tie Beams | . 15 |
| 4.9 | Creating Reinforcement by Rebar Components and Rebar Groups | . 16 |
| 4.10 | Creating Steel Members for ELS | . 18 |
| 4.11 | Creating Hoarding | . 18 |
| 4.12 | Creating Street Furnitures | . 20 |
| 4.13 | Creating Monitoring Instruments | . 21 |
| 4.14 | Attaching 3D topographic models | . 22 |
| 4.15 | Creating Ground Investigation Data | . 23 |
| 4.16 | Creating Steel Connections | . 27 |
| 4.17 | Creating Curtain Wall Elements | . 28 |
| 4.18 | Creating native Tekla elements from IFC objects | . 28 |
| | Har 1.1 Tek 2.1 2.2 2.3 2.4 2.5 2.6 2.7 2.8 2.9 2.10 2.11 Get 3.1 3.2 3.3 Creat 4.1 4.2 4.3 4.4 4.5 4.6 4.7 4.8 4.9 4.10 4.11 4.12 4.13 4.14 4.15 4.16 4.17 4.18 | Hardware / System Requirements 1.1 General Tekla Basics 2.1 User Interface 2.2 Project base point, Grid, Levels and Work Planes 2.3 Parts and Components 2.4 Catalogs and Define Profiles 2.5 Phases, View Filter and Organiser. 2.6 Suggested Model Nesting Method, Reference Models and Model Sharing 2.7 Views and Drawings 2.8 Annotation and Dimensioning 2.9 Template Editor, Tables and Drawing Layout. 2.10 2D Library and Symbol Editor 2.11 User Define Attributes Getting Start. Getting Start. 3.1 Opening Project Template 3.2 Set-up of Project Base Points 3.3 Creating Gids Creating Gums 4.2 4.2 Creating Babs 4.3 Creating Columns 4.4 Creating Bab Openings 4.5 Creating Slab Openings 4.6 Creating Atoricase 4.7 Creating Beams 4.8 Creating Steel Members for ELS |

| 5 | 2D | drawing production | 30 |
|---|-----|--|----|
| | 5.1 | Creating GA drawings | 30 |
| | 5.2 | Inserting Views to Drawings | 32 |
| | 5.3 | Creating Text and 2D Typical Details to Drawings | 33 |
| | 5.4 | Adding Dimensions and Marks to Drawings | 34 |
| | 5.5 | Creating Title Blocks and Schedules to Drawings | 35 |
| 6 | Exp | oorting Tekla Models as Deliverables | 38 |
| | 6.1 | Exporting 3D models as ifc | 38 |
| | 6.2 | Exporting 2D drawings as pdf or dwg | 39 |

Preface

The Construction Industry Council (CIC) is committed to seeking continuous improvement in all aspects of the construction industry in Hong Kong. To achieve this aim, the CIC forms Committees, Task Forces and other forums to review specific areas of work with the intention of producing Alerts, Reference Materials, Guidelines and Codes of Conduct to assist participants in the industry to strive for excellence.

The CIC appreciates that some improvements and practices can be implemented immediately whilst others may take more time for implementation. It is for this reason that four separate categories of publication have been adopted, the purposes of which are as follows:

| Alerts | The Alerts are reminders in the form of brief leaflets produced quickly to draw the immediate attention of relevant stakeholders to the need to follow some good practices or to implement some preventive measures in relation to the construction industry. |
|------------------------|---|
| Reference Materials | The Reference Materials are standards or methodologies generally adopted and regarded by the industry as good practices. The CIC recommends the adoption of the Reference Materials by industry stakeholders where appropriate. |
| Guidelines | The Guidelines provide information and guidance on particular topics relevant to the construction industry. The CIC expects all industry stakeholders to adopt the recommendations set out in the Guidelines where applicable. |
| Codes of Conduct | The Codes of Conduct set out the principles that all relevant industry participants should follow. Under the Construction Industry Council (Cap 587), the CIC is tasked to formulate codes of conduct and enforce such codes. The CIC may take necessary actions to ensure compliance with the codes. |

If you have read this publication, we encourage you to share your feedback with us. Please take a moment to fill out the Feedback Form attached to this publication in order that we can further enhance it for the benefit of all concerned. With our joint efforts, we believe our construction industry will develop further and will continue to prosper for years to come.

Foreword

I am glad to see the release of CIC BIM User Guide for Preparation of Statutory Plan Submissions Tekla (December 2020). This software specific user guide shall be read in conjunction with the CIC BIM Standards for Preparation of Statutory Plan Submissions (December 2020).

This software specific user guide is only provided to demonstrate the feasibility of drawings generation with the Standards.

With the software specific user guides which contains step by step procedures of modelling, BIM users can easily apply the templates for the generation of statutory plan submission drawings.

Feedback on the CIC BIM User Guide for Preparation of Statutory Plan Submissions Tekla (December 2020) from practitioners subsequent to the issuance of this publication will be considered in future revisions.

On behalf of the CIC, I would like to thank everyone who has contributed to producing this CIC BIM User Guide for Preparation of Statutory Plan Submissions Tekla (December 2020), in particular to the members of the Task Force on BIM Standards.

Ar. Ada FUNG, BBS Chairperson Committee on Building Information Modelling Construction Industry Council December 2020

1 Hardware / System Requirements

1.1 General

Hardware / system requirement for modellings, coordination and visualisation on desktop/notebook computers and mobile devices should be determined by the BIM managers for different projects on a case by case basis. The minimum requirement varies for different applications, project sizes and operating systems.

https://teklastructures.support.tekla.com/support-articles/tekla-structures-2019-hardwarerecommendations

2 Tekla Basics

This guideline only provides the necessary information to produce 2D statutory submission drawings. Please refer to the official website linked below for a complete understanding of Tekla. <u>https://teklastructures.support.tekla.com/tekla-structures-2019-pdf-documentation</u>

2.1 User Interface

Information of user interface could be found in the official website here: https://teklastructures.support.tekla.com/2019/en/gen_interface_overview

2.2 Project base point, Grid, Levels and Work Planes

Project base point defines the origin (0,0,0) of the project coordinate system initially Location of point can be determined by the project team or BIM manager as a reference point. Steps to set up project base points in Tekla could be found from the official website here :

https://teklastructures.support.tekla.com/2019/en/int_base_point

Grids and Levels are essential for users to model and identify objects in Tekla effectively, Steps to set up girds and levels in Tekla could be found from the official website here :

https://teklastructures.support.tekla.com/2019/en/mod_grids https://teklastructures.support.tekla.com/2019/en/mod_creating_a_grid

Work Plane is a vital concept for users to model objects in Tekla, this official link is useful for users to understand work planes in Tekla :

https://teklastructures.support.tekla.com/190/en/mod_work_plane

2.3 Parts and Components

Tekla objects could be classified into parts, components, assemblies, cast units etc. In this user guide, users mainly need to use parts (for example; concrete parts such as beam, column, slabs and panels) and components (for example; rebar components). These official web pages provide good guidance for creating parts in Tekla:

https://teklastructures.support.tekla.com/190/en/mod_creating_and_modifying_structures

https://teklastructures.support.tekla.com/190/en/mod_creating_concrete_slab?da=_

Components in Tekla could greatly increase the efficiency of modelling works, information about components could be found in this official web site:

https://teklastructures.support.tekla.com/2017i/en/det_getting_started_overview

2.4 Catalogs and Define Profiles

Tekla allow users to define customised profiles for members sections; users may refer to the link below for more information

https://teklastructures.support.tekla.com/2019/en/mod_profiles.

2.5 Phases, View Filter and Organiser

Phases are usually used by Tekla users to classify different object-groups (such as ELS, foundations or superstructures) in Tekla, differ from Revit, phase not necessarily be used to record sequential data of objects in Tekla. Users may use "Pour Phase" in Tekla to record chronological information of Tekla concrete parts. For steel parts and assemblies, part or assembly numbers are commonly used to achieve the same goal.

https://teklastructures.support.tekla.com/2019/en/mod_dividing_the_model_into_phases

In order to do 3d-modelling and produce drawings efficiently, phases are often used together with the view filter. View filter could also be used to control the visibility of different Tekla elements. More information about view filters could be found from the official website below :

https://teklastructures.support.tekla.com/190/en/mod_creating_a_view_filter

https://teklastructures.support.tekla.com/190/en/mod_filtering_parts_in_specific_phases

Organisers are used mainly for quantity take off purpose in Tekla, this web page provides more information about organiser in Tekla, in this document, organiser would not be discussed as it is not related to statuary drawing submissions.

https://teklastructures.support.tekla.com/2019/en/mod_organizer

2.6 Suggested Model Nesting Method, Reference Models and Model Sharing

Tekla is not designed to link-up with other Tekla models. For users who want to link two Tekla models together, they need to export one Tekla model as ifc and add that ifc model to another model via the "Reference Model" function in Tekla.

Information about the reference model could be found in this official web page ; files such as ifc, dwg, dgn, skp, xml, etc. could all be linked to Tekla by using this method.

https://teklastructures.support.tekla.com/2019/en/int_inserting_a_reference_model

2D reference information, such as 2D dwg/dgn maps bought from the Lands Department website shall also be linked to Tekla file by using a reference model.

Tekla allow multi-user-editing, please refer this web page for "Model Sharing" in Tekla

https://teklastructures.support.tekla.com/2019/en/ms_what_is_model_sharing

2.7 Views and Drawings

Views in Tekla are used to facilitate both 3D-modeling works and 2D drawing production. This web page summarises information about views in Tekla.

https://teklastructures.support.tekla.com/2019/en/mod_views

Users could produce 2D drawings after creating different views in Tekla. There are five different drawing types in Tekla, namely (1) general arrangement drawings, (2) single-part drawings, (3) assembly drawings, (4) Cast-unit drawings and (5) Multidrawings.

For the production of statutory-submission, only general arrangement drawings will be discussed in this user guide. Please refer to the link below for more information about creating general drawings by Tekla. Tekla will be switched from modelling mode to drawing mode for drawing production.

https://teklastructures.support.tekla.com/2019/en/dra_creating_ga_drawings_using_menu_t oolbar_or_popup

2.8 Annotation and Dimensioning

Users can create annotation and dimensions on drawings in drawing mode. Below are some web page links for more information.

https://teklastructures.support.tekla.com/2019/en/dra_arranging_drawing_objects

https://teklastructures.support.tekla.com/2019/en/dra_manual_dimensions

2.9 Template Editor, Tables and Drawing Layout

Drawing frames, or so we call title block, were produced by template editor in Tekla. Template editor could also be used to produce schedules or tables in 2D drawings. This video provides a brief introduction about template editor in Tekla.

https://teklastructures.support.tekla.com/video-tutorials/en/layout_editor

https://teklastructures.support.tekla.com/system/files/document_attachments/TE_USG_380 _en_Template_editor_user_guide.pdf

This video shows how the template editor could be used to produce schedules in 2D drawings. https://teklastructures.support.tekla.com/video-tutorials/en/introduction to template editor

2.10 2D Library and Symbol Editor

Tekla has some features to enable users to manage 2D drawing pieces and 2D symbols. They are namely the 2D Library and symbol editor. Please refer to the links below for more information.

https://teklastructures.support.tekla.com/video-tutorials/en/2d_library

https://teklastructures.support.tekla.com/video-tutorials/en/add symbols

https://teklastructures.support.tekla.com/system/files/document_attachments/SE_USG_300_en_S ymbol_editor_user_guide.pdf

2.11 User Define Attributes

Tekla enables users to introduce user-defined-attributes (UDA) to manage information about Tekla objects. An example of applying UDA to Tekla objects is provided as bored piles in the sample models. This requests users to acquire advanced Tekla skills, including some basic coding skills. For those who are interested, please refer to the link below, this user guide would not discuss this in detail.

https://teklastructures.support.tekla.com/cs/191/en/sys_example_creating_and_updating_uda

To manage UDA efficiently, Users may also search UDA in Tekla Warehouse and install more extensions:

https://warehouse.tekla.com/#!/search/?searchTerm=uda

Information stored in Tekla as UDA could also be exported to IFC as IFC property set, please refer to the link below for more information ;

https://teklastructures.support.tekla.com/2019/en/int_defining_property_sets_using_proper ty_set_definitions

3 Getting Start

Users are expected to install Tekla 2019i before followings the steps stated in this section.

3.1 Opening Project Template

Download template file from CIC website. Run the Env_SE_Asia_2019.exe to install Asian Tekla tool set. Put the folder set ""CIC_TEMPLATE_STR_2019" to C:\ProgramData\Trimble\Tekla Structures\2019.0\Environments\SE_Asia\Precast\model_templates.

Open Tekla 2019, open new file with template "CIC_DEMO_MODEL_TEMPLATE" being chosen.



3.2 Set-up of Project Base Points

Chose a reference point in the target project. Enter the Easting and Northing coordinates to Tekla by clicking the "base point" button in the project property menu as shown in the pictures below



3.3 Creating Grids

On the Edit tab, click Grid > Create rectangular grids as shown in the picture below; click "create rectangular grids" again to create another grid system if needed. The user could also create radial grids by choosing "Create radial grid". Unlike Revit, Tekla uses grids in the Z dimension to define building levels. For details about grids in Tekla, please refer to the reference links in section 2.2 in this user guide.

Grids are useful to control 3D objects in Tekla. Users could switch on or switch off the magnetic function of grids. The magnetic function is also available in construction lines and planes in Tekla. Users could use construction lines and construction planes as a temporary 3D reference during 3D modelling. Please refer to the link below for more information:

https://teklastructures.support.tekla.com/video-tutorials/en/magnetic_construction_objects



4 Creating Model Objects

The following objects will be modelled in Tekla:

- Slab
- Column
- Wall
- Beam
- Lift Shaft
- Staircase
- Piles
- Pile Caps
- Tie Beams
- Reinforcement
- Steel members for ELS
- Hoarding
- Geotechnical Monitoring instruments

4.1 Creating Slabs

On the View tab, click View tab > new view > along gridline to create views for specific floor levels, click Work Plane > Parallel to view plane to create work plane parallel to the view. For the snap settings which could be adjusted at the right bottom corner choose a plan, work plan and grid plane in the three put down the menu. Press ctrl+P to get a top view in Tekla modelling space,



Concrete tab, click Slab > Slab as shown in the picture below, left-click to define corner points of the slab, press middle mouse button to finish. Slab thickness can be adjusted in the property menu on the right.



4.2 Creating Columns

26325.00 mm

0.000000

0.00 mm

0.00 mm

0.000000

More

Bottom
Cast unit
Deforming
Warping

Cambering Shortening

More

▼ Custom properties

Modify 🛔

On the Concrete tab, click Column to create a column. Left-click in 3D model space to create a column. In the property menu, assign a name for the column; simply change the numbers in the profile entry in property menu (such as 250*675 or 400*600) to adjust column size; type D-diameter length (such as D1800) to change it to a circular column. Press three dots at the right for specific section profile. Change values in Top and Bottom to adjust column elevation. Right-click the column and choose move special > linear to fine adjust the position of the column in 3D space.



4.3 Creating Panels (Walls)

On the concrete tab, click Panel > Panel to create walls. Left-click to define wall alignment on the plan view, press middle mouse button to finish. In the property menu, assign a name for the wall, Wall height and wall thickness can be adjusted in the profile entry in the property menu.



4.4 Creating Beams

On the Concrete tab, click Beam > beam to create beams. Left-click in 3D model space to define endpoints of the beam. In the property menu, assign a name for the beams; like columns, simply change the numbers in the profile entry in property menu (such as 400*600 or 200*300) to adjust beam size; press three dots at the right for specific section profile. Right-click the beams and choose move special > linear to fine adjust the position of the beams in 3D space.



For specially shaped beams such as haunch beam, stepped beams and cranked beams, it is suggested to use polygon cut to remove unwanted portion of the beam.



4.5 Creating Slab Openings

Left-click the slab which needs to create slab opening, on the concrete tab, Press "ctrl+P" to get a top view in Tekla modelling space, choose polygon cut on the concrete tab to create slab opening.

4.6 Creating a Staircase

Click the application & components tab the right, search stair and chose concrete stair (component number 65) to create stair. Double-click the blue "M" symbol to adjust the properties of a component, click Modify > Apply > Okay to finish. Click the green buttons at the selection switches at the bottom to enable/disable user's ability to choose parts inside components. Delete unwanted components if necessary. Deleted parts in the component will be regenerated whenever users click Apply > Okay in the component property menu.





4.7 Creating Piles

Concrete piles are created in Tekla by using concrete columns while steel piles are created by using steel columns, please refer to section 4.2 in this user guide for detail.

Users may download the Bellout.uel profile file from the CIC website if they want to model bored piles with bellout. Import the uel file from "Profile Catalog" which could be found in the file menu at the top right corner (see the user interface at "General" in this user guide). "Profile Catalog" is under the catalogues tag.



4.8 Creating Pile Caps and Tie Beams

Pad footing is used to create a pile cap in Tekla. It is suggested to create a one big rectangular box model by using pad footing and then trim it by using polygon cut. It is not suggested to use more than one pad footing to model one pile cap as this would cause problems during 2D drawing production.



To minimise the use of polygon cuts, it is suggested to use custom profiles to create footing with a shape which can be created by simple extrusions, such as the triangular pile cap as shown below. Users may use "define cross-section in sketch editor" to create custom profiles.

Tie beams should be modelled by using strip footing under the Concrete > Footing tab.



4.9 Creating Reinforcement by Rebar Components and Rebar Groups.

Click the application & components tab the right, search beam / column / wall / slab rebars to create rebars. Click the concrete parts such as beams and columns in modelling space to assign rebar. If necessary, users could right-click and select explode component after selecting specific rebar components, such that rebar components will be broken down to different rebar groups. This will not affect 2D drawing production.

Users may also create rebar groups by clicking Rebar > Rebar group on the concrete tab. Properties of the rebars could be adjusted in the rebar group property menu on the right.





in the rebar group property menu, it is suggested to assign rebar layer name (such as T1, T2, B1, B2) in the Name entry. "Prefix" in the "Numbering entry" to specify zone information (such as STR for superstructure or FND for foundation) and the "Start number" in the "Numbering Entry" to specify the bar marks.

The purpose of specifying zone information is to control the visibility of rebars in 3d models and 2D drawings. This setting could be used together with phase manager in 3d modelling mode and view filter function in both 3d modelling mode and 2d drawing mode to control the visibility of objects in complex Tekla models.

Users may also control end conditions of the rebar group by adjusting values in the "Hooks" entries in the rebar group property menu.



Users could also create rebars by using rebar sets. Rebar set is a powerful tool to enable users to create 3D rebars effectively. More settings are needed in advance for users to create rebars by using rebar set. For simplicity, only rebar component and rebar group are discussed in this user guide. No matter rebars are modelled by rebar components, rebar groups or group sets, detailed reinforcement drawings could also be produced by Tekla in 2D drawing mode. As both rebar groups and rebar sets contain information of name, numbering prefix and numbering start number. Tagging of rebar would not be affected during 2D drawing production.

4.10 Creating Steel Members for ELS

Steel members in excavation lateral support system could be modelled by using column and beam under Steel tab. Method of modelling is just similar to concrete columns and beams as specified in section 4.2 and 4.4 in this user guide.



4.11 Creating Hoarding

Model concrete footings of the site hoarding by using the concrete panel, as mentioned in section 4.3. Model steel posts of site hoarding by using steel columns. After footings and steel posts were modelled, model a thick concrete panel to indicate the area of the covered walkway as shown in the pictures below. Specify the type of the hoarding in the name entry in property menu for tagging in 2D drawings.







4.12 Creating Street Furnitures

Tekla is not designed to model street furniture such as light posts, traffic lights, guard rail, manhole covers, fire hydrants etc. Users may download these 3D models from Trimble SketchUp 3D warehouse and turn those skp files to Tekla objects.

On the concrete tab, choose item, under the property meun pick the three dots at the right of the shape entry. 3D models in .tsc / .skp / .dxf / .dwg / .ifc / .ifczip / .ifcXML / .igs /iges / .dgn / .stp or .step format could be imported into Tekla by this method.

Users may also buy 2D maps in dwg or dgn format from Lands Department website and import those files to Tekla by using the Reference model function, as mentioned in section 2.6 in this user guide.

Sketchup 3D warehouse:

https://3dwarehouse.sketchup.com/



4.13 Creating Monitoring Instruments

It is suggested to create a simple box model in Tekla to represent geotechnical monitoring instruments such that objects could be scheduled if needed. Users could choose whether to insert 3D instrument model by using "shape" in "concrete items" as mentioned in section 4.12 in this user guide or simply use native concrete parts to create a box model such that the space consumed by the instrument could be adjusted inside Tekla. Name the instrument in the name entry in property menu such that the name could be shown by using associative note in the drawing.

It is suggested to use a symbol in part mark to denote the location and type of the instrument and use an associative note to denote the name. Such that information could be shown clearly on 2D drawings, even some instruments are put very close to each other.



4.14 Attaching 3D topographic models

Tekla is not designed to model 3D topographic models, but users could attach 3D topographic models from other software to Tekla through the 'Reference Model: function. Users need to name those reference model systematically in order to manage their visibility in 2D drawings.





4.15 Creating Ground Investigation Data

Rock core samples from the bored hole and standard penetration tests results are needed to be modelled in 3D for drawing production. A Grasshopper script could be downloaded from the CIC website to facilitate users to model this information in 3D.



First users need to organise GI data in Excel as shown in the picturesm below for rock core samplesintheboredholeandSPTresults.Name

| File Home Insert Page Layout Formulas Data Review View Add-ins BLUEBLAM Pate | Ro | | | | | | | | | | 5 | C. |
|---|----|----------------------|-----------------------|----------------------------|--------|--------------|----------|-----------|---------------|------|-----------|-----|
| A B C D E F E | | BLUEBEAM | Vdd-ins | View A | new . | Data Rev | Formulas | ge Layout | Insert Pag | ome | le H | |
| Clipboard 5 Font 6 Alignment 65 ILD - <th>6</th> <th>æ .</th> <th>≫- ⊑ •≣</th> <th></th> <th>(0. JI</th> <th>A' = ▲· ≡</th> <th>A - A</th> <th>e - 10</th> <th>MS Sans Serif</th> <th></th> <th></th> <th>Pa</th> | 6 | æ . | ≫- ⊑ •≣ | | (0. JI | A' = ▲· ≡ | A - A | e - 10 | MS Sans Serif | | | Pa |
| ID ID ID ID E F A B C D E F I BH nc, 2 Sol / Pack Layer Northing Layer Top Level Layer Top Level <t< td=""><td></td><td>6</td><td>nt</td><td>Alignme</td><td></td><td>6</td><td></td><td>Font</td><td></td><td>75</td><td>Clipboard</td><td></td></t<> | | 6 | nt | Alignme | | 6 | | Font | | 75 | Clipboard | |
| A B C D E F 1 BH no. Soil / Pock Layer Easting Northing Layer Top. Level (mPD) Level (mPD) 2 BH1 FILL 805036517 819787683.8 4019447 +4460.653 4500.553 3 BH1 V 835638517 819787683.8 4000.653 4600.653 4600.653 4400.653 4 BH1 II 835638517 819787853.8 4600.653 -2740.6529 600.653 -2740.6529 -2740.6529 -2740.6529 -2740.6529 -2740.6529 -2740.6529 -2740.6529 -2740.6529 -2740.6529 -2740.6529 -33780.6529 -2740.6529 -33780.6529 -337 | | | | | | | | fi | XV | - | | 110 |
| I BH no. Soil / Pack Layer Easting Northing Layer Top Level (mPD) Layer Entrom Level (mPD) 2 BH1 FILL 836336517 819787853.8 4019.447 Layer 500 (mPD) 3 BH1 V 835338517 819787853.8 44260.553 4980.553 4 BH1 II 855328517 819787853.8 44260.553 4980.653 5 BH1 V 835328517 819787853.8 4900.553 2740.5529 6 BH1 V 835338517 819787853.8 -2740.5529 -3170.5529 7 BH1 II 835336517 819787853.8 -3010.5529 -33180.5529 8 BH1 IV 835336517 819787853.8 -30400.5529 -33800.5529 9 BH1 II 835336517 819787853.8 -30400.5529 -33800.5529 10 BH1 III 835336517 819787853.8 -9880.5528 -40130.5528 12 BH1 III 835336517 <td>G</td> <td>e 10 v</td> <td>F</td> <td>E</td> <td></td> <td>D</td> <td>c</td> <td>1</td> <td>В</td> <td></td> <td>A</td> <td>ali</td> | G | e 10 v | F | E | | D | c | 1 | В | | A | ali |
| 2 BH1 FILL 895336517 819787853.8 4013.447 -4480.553 3 BH1 V 835338517 819787853.8 -4480.553 -6960.553 4 BH1 I 835338517 819787853.8 -4480.553 -4480.553 5 BH1 V 835338517 819787853.8 -6460.553 -2440.553 6 BH1 V 835338517 819787853.8 -2440.552 -00100.5529 7 BH1 III 835338517 819787853.8 -30100.5529 -33780.5529 7 BH1 III 835338517 819787853.8 -30100.5529 -33780.5529 8 BH1 IV 935335517 819787853.8 -30400.5529 -30800.5529 9 BH1 II 835338517 819787853.8 -36800.5529 -30800.5529 10 BH1 911 835338517 819787853.8 -41800.5528 -41090.5528 12 BH1 II 835338517 819787853.8 | | Sottom vel PD1 | Layer E Ler (mF | ayer Top Level (mPD) | La | Northing | sting | Ea | / Rock Laver | Soil | BH no. | 1 |
| 3 BH1 V 383538517 81978785.8 -4480.553 -5680.553 4 BH1 II 936338517 81978785.8 -4480.553 -4480.553 5 BH1 V 936338517 81978785.8 -4600.553 -2480.552 6 BH1 V 936338517 819787858.8 -2440.552 -33180.552 7 BH1 IV 935338517 819787858.8 -33180.552 -33180.552 -33180.552 -33180.552 -33180.552 -3380.552 -3380.552 -3380.552 -36800.552 -36800.552 -36800.552 -36800.552 -36800.552 -36800.552 -36800.552 -36800.552 -36800.552 -36800.552 -36800.552 -36800.552 -36800.552 -36800.552 -36800.552 -36800.552 -41730.552.8 -4180.552.8 -4180.552.8 -4180.552.8 -4180.552.8 -4180.552.8 -4180.552.8 -4180.552.8 -4180.552.8 -4180.552.8 -4180.552.8 -4180.552.8 -4180.552.8 -4180.552.8 -4180.552.8 -4180.552.8 -4180.552.8 | |).553 | -4480 | 019.447 | 40 | 819787853.8 | 38517 | 8353 | FILL | | BH1 | 2 |
| 4 BH1 II 935328517 810787853.8 -6000.653 -9440.6529 6 BH1 V 935336517 810787853.8 -8400.652 -2740.6529 6 BH1 IV 935336517 819787853.8 -30100.6529 -30100.5529 7 BH1 III 835336517 819787853.8 -30100.6529 -34680.6529 8 BH1 IV 936338517 819787853.8 -33780.6529 -34680.6529 9 BH1 III 935336517 819787853.8 -36800.6529 -38680.5529 10 BH1 III 835336517 819787853.8 -56800.5529 -38680.5529 11 BH1 III 835336517 819787853.8 -98800.5529 -4030.5528 12 BH1 III 835336517 819787853.8 -41800.5528 -41600.5528 13 BH1 III 835336517 819787853.8 -41800.5528 -44300.5528 15 BH1 III 835336517 8 | | .553 | -5980 | 480.553 | -4- | 819787853.8 | 38517 | 8353 | V | | BH1 | 3 |
| 5 BH1 V 98539617 81078785.8 -8400 F53 -27400 F529 6 BH1 IV 80533617 81078785.8 -3840 F53 -27400 F529 -30100 5529 7 BH1 III 836336517 819787853.8 -33700 F529 -33780 F529 -33780 F529 8 BH1 IV 936336517 819787853.8 -33700 F529 -36600 5529 -36600 5529 -36600 5529 -36600 5529 -36600 5529 -36600 5529 -36600 5529 -36800 5529 -36800 5529 -39380 5529 -39380 5529 -39380 5529 -39380 5529 -39380 5529 -39380 5529 -39380 5529 -39380 5529 -39380 5529 -39380 5528 -41090 5528 -41090 5528 -41090 5528 -41800 5528 - | |).663 | -8480 | 980.663 | -64 | 819787863.8 | 38517 | 8353 | 11 | | BH1 | 4 |
| 6 BH1 IV 835336517 819787653.6 -2740,5529 -33100,5529 7 BH1 II 835336517 819787653.8 -30100,5529 -33180,5529 8 BH1 IV 895338517 819787653.8 -30100,5529 -33180,5529 8 BH1 IIV 895338517 819787653.8 -4680,5529 -33800,5529 10 BH1 III 635335617 819787853.8 -5660,5529 -33800,5529 11 BH1 III 835335617 819787853.8 -5680,5529 -33800,5529 12 BH1 III 835335617 819787853.8 -5980,5529 -40730,5523 13 BH1 III 835335617 819787853.8 -4180,5528 -4180,5528 14 BH1 III 835335617 819787853.8 -4180,5528 -4250,5528 15 BH1 III 835336517 819787853.8 -4180,5528 -4380,5528 15 BH1 III 835336517 8 | | .5529 | -27480 | 480.553 | -8- | 819787853.8 | 38517 | 8353 | V | | BH1 | 6 |
| 7 BH1 III 385338617 819787853.8 -90100.5529 -93780.5529 8 BH1 IV 985338617 819787853.8 -90100.5529 -34680.5529 8 BH1 III 985338617 819787853.8 -93780.5529 -34680.5529 10 BH1 III 935338517 819787853.8 -9660.5529 -33800.5529 11 BH1 III 935338517 819787853.8 -98606.5529 -33930.5529 12 BH1 III 935338517 819787853.8 -9800.5529 -40730.5528 13 BH1 III 935338517 819787853.8 -41090.5528 -41090.5528 14 BH1 III 935338517 819787853.8 -4180.5528 -44360.5528 15 BH1 III 935338517 819787853.8 -4180.5528 -43800.5528 15 BH1 III 935338517 819787853.8 -4260.5528 -43800.5528 17 BH1 III 935338517 | |).5529 | -30100 | 480.5529 | -27- | 819787853.8 | 38517 | 8353 | IV . | | BH1 | 6 |
| 8 BH1 IV 985328617 810787853.8 -93780.6520 -94680.5520 9 BH1 II 035536517 819787853.8 -93820.6529 -96800.5529 10 BH1 II 035538517 819787853.8 -93820.5529 -33800.5529 11 BH1 III 835338517 819787853.8 -95800.5529 -33800.5529 12 BH1 III 835338517 819787853.8 -95800.5529 -40730.5528 13 BH1 III 835338517 819787853.8 -41090.5528 -4180.5528 14 BH1 III 835338517 819787853.8 -4180.5528 -4180.5528 15 BH1 III 835338517 819787853.8 -4180.5528 -4250.5528 16 BH1 III 835338517 819787853.8 -42800.5528 -42800.5528 17 BH1 III 83538517 819787853.8 -42800.5528 -42800.5528 18 BH1 III 835338517 | | .5529 | -33780 | 100.5529 | -30 | 819787853.8 | 38517 | 8353 | 111 | | BH1 | 7 |
| 9 BH1 III 95536517 81978765.8 -94680,5529 -36800,5529 10 BH1 II 835335517 81978765.8 -36800,5529 -38300,5529 11 BH1 III 835335517 819787853.8 -36800,5529 -33330,5529 12 BH1 III 835335517 819787853.8 -36800,5529 -40730,5528 13 BH1 III 835335517 819787853.8 -40730,5528 -4180,5528 14 BH1 II 835335517 819787853.8 -4109,5528 -4180,5528 15 BH1 III 835335517 819787853.8 -4180,5528 -4380,5528 16 BH1 III 835335517 819787853.8 -4260,5528 -4380,5528 17 BH1 III 835335517 819787853.8 -4260,5528 -4380,5528 18 BH1 III 835335517 819787853.8 -4430,5528 -4250,5528 20 BH2 FILL 835550267.7 <t< td=""><td></td><td>.5529</td><td>-34680</td><td>780.5529</td><td>-33</td><td>819787853.8</td><td>38517</td><td>8353</td><td>IV.</td><td></td><td>BH1</td><td>8</td></t<> | | .5529 | -34680 | 780.5529 | -33 | 819787853.8 | 38517 | 8353 | IV. | | BH1 | 8 |
| ID BH1 II 385338517 819787853.8 -36600.5529 -38800.5529 12 BH1 II 835338517 819787853.8 -38600.5529 -39300.5529 12 BH1 II 835338517 819787853.8 -39800.5529 -40730.5528 13 BH1 III 835338517 819787853.8 -4030.5528 -41090.5528 14 BH1 III 835338517 819787853.8 -41090.5528 -41690.5528 15 BH1 III 835338517 819787853.8 -41800.5528 -42600.5528 15 BH1 III 835338517 819787853.8 -41800.5528 -42600.5528 16 BH1 III 835338517 819787853.8 -41800.5528 -44300.5528 17 BH1 III 835338517 819787853.8 -43400.5528 -44300.5528 18 BH1 II 835338517 819787853.8 -44390.5528 -44390.5528 20 BH1 III 835338517 | | .5529 | -36860 | 680.5529 | -34 | 819787853.8 | 38517 | 8353 | 111 | | BH1 | 9 |
| II BHI III 935336517 81.978785.3 -93800.5529 -40305.5529 12 BHI II 035336517 61.978785.3 -93800.5529 -40730.5528 13 BHI III 035336517 61.9787853.8 -93800.5529 -40730.5528 14 BHI III 035336517 61.9787853.8 -41690.5528 -41690.5528 15 BHI III 835336517 81.9787853.8 -41800.5528 -4260.5528 15 BHI III 835336517 81.9787853.8 -41800.5528 -4260.5528 16 BHI III 035536517 81.9787853.8 -43400.5528 -43800.5528 17 DHI III 03535617 81.9787853.8 -43400.5528 -44300.5528 18 BHI III 835336517 81.9787853.8 -44520.5528 -44530.5528 20 BHI III 03530507.7 81.9787874.4 4000.0055 -50.07123 21 BH2 FLL 035350267. | | 5529 | -38800 | 860.5529 | -36 | 819787853.8 | 38517 | 8353 | 11 | | BH1 | 10 |
| 12 BH1 II 836338517 819787858.8 -96960 F529 -40730 5528 13 BH1 III 895336517 819787858.8 -96960 F529 -40130 5528 14 BH1 II 835336517 819787858.8 -41090 5528 -41800 5528 15 BH1 III 835336517 819787858.8 -41190 5528 -421800 5528 15 BH1 III 835336517 819787858.8 -41800 5528 -42400 5528 16 BH1 III 835336517 819787858.8 -42600 5528 -43400 5528 17 BH1 III 835336517 819787858.8 -43600 5528 -43800 5528 18 BH1 III 835338517 819787858.8 -44300 5528 -44300 5528 20 BH1 III 835358517 819787858.8 -44200 5528 -47970 5528 21 BH2 FILL 835550267.7 81978977.4 -4000 0056 -2100 0123 22 BH2 MD 835580267.7 </td <td></td> <td>5529</td> <td>-39380</td> <td>800.5529</td> <td>-98</td> <td>819787853.8</td> <td>38517</td> <td>8353</td> <td>111</td> <td></td> <td>BH1</td> <td>11</td> | | 5529 | -39380 | 800.5529 | -98 | 819787853.8 | 38517 | 8353 | 111 | | BH1 | 11 |
| 13 BH1 III 95536517 919787553.8 -40705528 -410905523 14 BH1 II 83538517 819787853.8 -416905528 -416905528 15 BH1 III 83538517 819787853.8 -416905528 -425605528 15 BH1 III 83538517 819787853.8 -416905528 -426005528 17 BH1 II 836538517 819787853.8 -424005528 -436005528 18 BH1 III 83538517 819787853.8 -434005528 -436005528 19 BH1 III 83538517 819787853.8 -436005528 -452605528 20 BH1 III 83538517 819787853.8 -442905528 -452605528 20 BH1 III 895385617 819787853.8 -442905528 -452605528 21 BH2 FLL 8355802677 819787974 400000505 -2100122 22 BH2 MD 8358502677 819787974 | | .5528 | -40730 | 380.5529 | -39 | 819787853.8 | 38517 | 8353 | 11 | | BH1 | 12 |
| 14 BH1 II 835336517 819737853.8 -41090.5528 -41380.5528 15 BH1 III 835336517 819737853.8 -41280.5528 -42560.5528 15 BH1 II 835336517 819787853.8 -42660.5528 -43430.5528 17 BH1 II 835336517 819787853.8 -4260.5528 -43430.5528 18 BH1 III 835336517 819787853.8 -4340.5528 -44930.5528 19 BH1 III 835336517 819787853.8 -44490.5528 -44930.5528 20 BH1 III 835336517 819787853.8 -44930.5528 -44590.5528 21 BH2 FILL 835550267.7 819789797.4 -2100.0123 -3999.9633 22 BH2 MD 835850267.7 819789797.4 -2100.0123 -3999.9633 23 BH2 V 935850267.7 819789797.4 -200.0123 -3999.9633 24 BH2 II 835580267.7 | |).5528 | -41090 | 730.5528 | -40 | 819787853.8 | 38517 | 8353 | 111 | | BH1 | 13 |
| 15 BH1 III 285328617 81978785.3 -4180.5528 -4260.5528 -4260.5528 16 BH1 II 635326517 81978785.3 -4260.5528 -4260.5528 -4260.5528 17 BH1 III 635336517 81978785.3 -4260.5528 -4340.5528 18 BH1 II 83533617 81978785.3 -4340.5528 -4340.5528 19 BH1 II 83533617 81978785.3 -4340.5528 -4450.5528 20 BH1 II 83535617 81978758.3 -44290.5528 -45260.5528 21 BH2 FILL 835550267.7 81978975.4 -4000.0055 -2100.0123 22 BH2 MD 835850267.7 81978975.4 -4000.0055 -2100.0123 23 BH2 V 835850267.7 81978917.4 -2100.0123 -8999.9933 24 BH2 II 835850267.7 81978917.4 -2000.0123 -3999.9933 23 BH2 V | | 5528 | -41880 | 090.5528 | -41 | 819787853.8 | 38517 | 8353 | it. | | BH1 | 14 |
| 16 BH1 II 89539617 81978785.8 42660.5528 44340.5528 17 BH1 III 89539617 01970765.8 -43400.5528 -43400.5528 18 BH1 II 83533817 81978785.8 -43400.5528 -443400.5528 19 BH1 II 83533817 81978785.8 -43400.5528 -44500.5528 20 BH1 II 8353502677 81978785.8 -44290.5528 -44500.5528 21 BH2 FLL 8355502677 819789797.4 -2100.0125 -3999.9933 22 BH2 MD 835850267.7 819789797.4 -2100.0125 -3999.9933 23 BH2 V 93580267.7 819789707.4 -200.0123 -3999.9933 24 BH2 II 80550267.7 819789707.4 -200.0123 -3999.9933 24 BH2 II 80550267.7 819789707.4 -4000.0031 -1609.9931 | | 0.5528 | -42560 | 880.5528 | -41 | 819787853.8 | 38517 | 8353 | 111 | | BH1 | 15 |
| 17 BH1 III e35536517 919787653 -44340.5528 -44360.5528 18 BH1 II e35538517 819787853.8 -44300.5528 -44930.5528 19 BH1 III e35538517 819787853.8 -44930.5528 -4450.5528 20 BH1 III e35538517 819787853.8 -4450.5528 -4520.5528 21 BH2 FILL e35550267.7 819789797.4 -4000.0055 -2100.0123 22 BH2 MD e35550267.7 819789797.4 -2100.0123 -3999.9633 23 BH2 V 935850267.7 819789707.4 -2000.0123 -3999.9633 24 BH2 II e35550267.7 819789707.4 -2000.0123 -3999.9633 23 BH2 V 935850267.7 819789707.4 -3009.0033 -1609.00831 24 BH2 II e35580267.7 819789707.4 -1409.939.31 -15699.989.31 | | .5528 | -43430 | 560.5528 | -429 | 819787853.8 | 38517 | 8353 | 11 | | BH1 | 16 |
| 18 BH1 II 38538617 319787653.8 -43800.5528 -44300.5528 19 BH1 III 39539517 319787653.8 -44390.5528 -45250.5528 20 BH1 II 93539617 319787653.8 -44526.5528 -45250.5528 21 BH2 FILL 035590267.7 019798787.4 4000.0055 -3999.9533 22 BH2 MD 835580267.7 81978707.4 -2100.0123 -8999.9633 23 BH2 V 835580267.7 819789707.4 -9009.0033 -14090.9031 24 BH2 II 835850267.7 819789707.4 -1409.9031 -15699.9031 | | 5528 | -43800 | 430.5528 | -43- | 819787853.8 | 38517 | 8353 | 111 | | BH1 | 17 |
| 19 BH1 III 85532617 81978785.8 -44290.5528 -45200.5528 20 BH1 II 89532617 81978785.8 -46200.5528 -45200.5528 21 BH2 FLLL 895350267.7 819789787.4 4000.0055 -2100.0125 22 BH2 MD 835850267.7 819789797.4 -2100.0125 -3999.9933 23 BH2 V 895850267.7 819789797.4 -200.0123 -3999.9933 24 BH2 II 895850267.7 819789707.4 -3000.00331 -15699.9931 24 BH2 II 805850267.7 819789707.4 -14099.9931 15699.9931 | | 5528 | -44930 | 800.5528 | -43 | 819787853.8 | 38517 | 8353 | 11 | | BH1 | 18 |
| 20 BH1 II 83632617 819787653.8 -46260.6528 -47070.5523 21 BH2 FILL 835550267.7 819789797.4 4000.0085 -2100.0123 22 BH2 MD 835550267.7 819789797.4 -2100.0123 -3999.9933 23 BH2 V 935850267.7 819789707.4 -2000.0123 -3999.9933 24 BH2 II 835550267.7 819789707.4 -4009.0033 -16099.9931 24 BH2 II 835550267.7 819789707.4 -14099.9331 -15699.9831 | | .5528 | -45250 | 930.5528 | -44 | 819787853.8 | 38517 | 8353 | 111 | | BH1 | 19 |
| 21 BH2 FILL 835550267.7 619789787.4 4000.0065 -2100.0123 22 BH2 MD 835350267.7 819789197.4 -2100.0123 -8999.9933 23 BH2 V 895850267.7 819789197.4 -2000.0003 -14090.0003 24 BH2 II 895850267.7 819789177.4 -14099.9931 15699.9931 | | .5528 | -47970 | 250.5528 | -45 | 819787853.8 | 38517 | 8353 | 11 | | BH1 | 20 |
| 22 BH2 MD 835550267 319787197.4 -2100.0123 -99999333 23 BH2 V 895850267.7 819789707.4 -3000.0033 -14000.0031 24 BH2 II 895850267.7 819789707.4 -14099.9931 -15699.9931 | | 0123 | -2100 | 00.0065 | 40 | 819789797.4 | 60267.7 | 83535 | FILL | | BH2 | 21 |
| 23 BH2 V 835350267.7 819789797.4 -8099.9033 -14099.9031 24 BH2 II 835350267.7 819789797.4 -14099.9931 -15699.9931 | | 9933 | -3999 | 00.0123 | -21 | 819789797.4 | 0267 7 | 83535 | MD | | BH2 | 22 |
| 24 BH2 II 835350267.7 819789797.4 14099.9931 -15699.9931 | | 0.0981 | -14099 | 999.9933 | -80 | 819789797.4 | 0267.7 | 83535 | V | | BH2 | 28 |
| | | 9.9931 | -15699 | 099.9931 | -14 | 819789797.4 | 0267.7 | 83535 | 11 | | BH2 | 24 |
| | | | | | | | | | | - | | |
| | | | | | - | | | | | | | |

Number (mm)

Text

| 1 | | c ^a | | | | | | | | |
|----|-----------|-----------------------|----------|--------|--------------|-----------|------------|-----------|----------|--------|
| 1 | nie i | Home | Insert | Page L | ayout | Formulas | Data | Review | v View | A |
| 1 | | κ. | MS Sans | Serif | * 10 | · A | Ă | = | = = | 1 |
| P | aste | * | В | I | J - [| I • 💁 • | <u>A</u> - | | 1 | 4 |
| | Clipboard | 15 | | | Font | | 5 | | Al | ignmei |
| K1 | 3 | • | \times | ~ f. | - | | | | | |
| | А | | в | | | с | 1 | D | E | |
| 1 | Count | | Easting | ŝ. | | Northing | Pos | sition Z | Value | |
| 2 | BH1 | 8 | 353385 | 17 | 81 | 9787853.8 | | 501.0366 | N=9 | |
| 3 | BH1 | 8 | 353385 | 17 | 81 | 9787853.8 | -1 | 498.9634 | N=10 | |
| 4 | BH1 | 8 | 3533851 | 17 | 81 | 9787853.8 | -4 | 998.9634 | N=15 | |
| 5 | BH1 | 8 | 353385 | 17 | 81 | 9787853.8 | -8 | 998.9634 | N=15 | |
| 6 | BH1 | 8 | 353385 | 17 | 81 | 9787853.8 | -1 | 0998.963 | N=19 | |
| 7 | BH1 | 8 | 3533851 | 17 | 81 | 9787853.8 | -1 | 2998.963 | N=24 | |
| 8 | BH1 | 8 | 3533851 | 17 | 81 | 9787853.8 | -1 | 4998.963 | N=26 | |
| 9 | BH1 | 8 | 353385 | 17 | 81 | 9787853.8 | -1 | 6998.963 | N=72 | |
| 10 | BH1 | 8 | 353385 | 17 | 81 | 9787853.8 | -1 | 8998.963 | N=76 | |
| 11 | BH1 | 8 | 3533851 | 17 | 81 | 9787853.8 | -2 | 0998.963 | N=97 | |
| 12 | BH1 | 8 | 353385 | 17 | 81 | 9787853.8 | -2 | 2998.963 | N=100 | |
| 13 | BH1 | 8 | 353385 | 17 | 81 | 9787853.8 | -2 | 4998,963 | N=97 | |
| 14 | BH1 | 8 | 323382 | 17 | 81 | 9787853.8 | -2 | 6998.963 | N=105 | |
| 15 | BH1 | 8 | 3533851 | 17 | 81 | 9787853.8 | -2 | 8998.963 | N=200/60 | |
| 16 | BH2 | 83 | 3535026 | 7.7 | 81 | 9789797.4 | 1 | 496.4827 | N=9 | |
| 17 | BH2 | 83 | 3535026 | 7.7 | 81 | 9789797.4 | | -503.5173 | N=11 | |
| 18 | BH2 | 83 | 3535026 | 7.7 | 81 | 9789797.4 | -3 | 603,5173 | N=11 | |
| 19 | BH2 | 83 | 3535026 | 7.7 | 81 | 9789797.4 | -4 | 1503.5173 | N=10 | |
| 20 | BH2 | 83 | 3535026 | 7.7 | 81 | 9789797.4 | -6 | 503.5173 | N=11 | |
| 21 | BH2 | 83 | 3535026 | 7.7 | 81 | 9789797.4 | -8 | 603.5173 | N=17 | |
| 22 | BH2 | 83 | 3535026 | 7.7 | 81 | 9789797.4 | -1 | 0503.517 | N=22 | |
| | | | _ | _ | | | | | | |
| | Y | | | | | | | | Y | |
| | Text | t | | Nu | mbe | er (mm |) | | Text | |

Second, after installing Rhino6, users could type "Grasshopper" on the command bar to open Grasshopper. After Grasshopper is opened, go to "File" at the top left corner and choose "Open Document" to open the "Tekla_GI Rock Core.gh" file to open the script.



Grasshopper - Tekla GI



25

After the "Tekla_GI Rock Core.gh" file is opened, right-click at the "File Path Component" and choose the Excel file the user had prepared for rock core samples. Then right-click at the "Tekla Column Component" at the right and choose "Bake to Tekla" to create 3D geometries in Tekla. Those 3D geometries created should be assigned to the "GI" Tekla phase and could be used for 2D drawing production.

For SPT information, open the "Tekla GI_SPT.gh" file, right-click at the "File Path Component" and choose the Excel file the user had prepared for SPT information and then bake those 3D object to Tekla by using the same method as mentioned above.



4.16 Creating Steel Connections

One of the main advantages of using Tekla lies in its capability to efficiently model all kinds of steel connections. Many connection types have an existing parametric component that the users can quickly edit to create the desired connections. Components are found in the "Applications & components" pane where users can search for the desired connection type (e.g. "end plate", "brace connection" or "shear plate").

Below are the search results for end plate connections. Double-clicking a component opens up its dialogue box where users can see how the component works and what parameters are available. In case of the component "End plate (101)", the user must select two pre-existing beams in the model to apply the connection at their intersection. After placing the connection, users can double-click the connection in the model to modify the parameters (e.g. set bolt spacing, size of plate etc.).





4.17 Creating Curtain Wall Elements

Curtain wall elements such as transoms and mullions can be either modelled by simple rectangular sections (e.g. RHS) or the actual profiles can be imported to Tekla. For the latter, users can create user-defined sections by sketching the section or importing from a DWG file.

| Menu | Catalogs | Define profiles | NALVSIS & DESIGN TRIMBLE CONNECT | r BRIDGES |
|----------------------------|---|--|---|---------------------------------------|
| Modeling | Profile catalog | Define cross section in sketch editor | 1 1 4 1 | |
| | Define profiles | Define cross section using polygon Define cross section using plate | Beam Panel Slab Poot | ting Hi Cast unit · Repar · |
| Open | Material catalog Boit catalog | Define cross section using DWG file Define profile with variable cross section Edit polycopy cross section | Load standard Picture Parameters Profile attributes | v Save as standard Help |
| 4 Printing | Bolt assembly catalog Shape catalog Rebar shape catalog | Europagon closs second | Input file Section name Profile name | V input.dwg |
| ← Import → Export | AutoConnection settings AutoDefaults settings | | Save to Min distance between points Center point offset x | Model directory V V |
| Sharing Project properties | | | Center point offset y Weight / m3 (kg/m3) | ✓ ✓ ✓ ✓ |
| Catalogs | | | | |
| E Logs | | | | |
| ? Help | | | OK Apply | Cancel |
| Exit Tekla Structures | | | | 3 |

4.18 Creating native Tekla elements from IFC objects

It is possible to convert IFC reference model objects to native Tekla elements using the "Convert IFC objects" tool. Users can choose to convert a portion of, or the entire IFC model. Users can overview the converted properties and choose the conversion type.







5 2D drawing production

5.1 Creating GA drawings

First In 3D modelling mode, choose the views needed for 2D drawing production. On the drawing tab, click create drawings > GA drawings. In the create General Arrangement Drawing pop-up window, choose empty drawings, tick the box of open drawing and then click "Create"



| liews | |
|----------------------|------|
| 5F Beam TB3 and 4 | |
| 5F Beam TB15 | |
| Foundation Section A | |
| Foundation Section B | |
| Frid PA | 1 |
| Frid Tl | |
| Grid T2 | |
| Grid T3 | |
| Frid T4 | |
| Grid T5 | |
| Frid TA | |
| Frid TB | |
| Frid TC | |
| Frid TD | |
| Srid TE | |
| Frid TF | |
| Grid TG | |
| Brid TH | |
| Srid TI | |
| Frid TJ | |
| Plan UmPD | |
| Plan 3/F | |
| Plan D/F | |
| Plan 6/F | |
| Plan Bl/F | |
| Plan B2/F | |
| Plan EGL | |
| flan G/F | |
| Alan Publi | |
| rian Forb | |
| Ontions | |
| matu danuina | |
| Drawing properties | |
| Open drawing | |
| 1 open district | |
| | - (/ |

Now Tekla is switched from 3D modelling mode to 2D drawing mode. Double click at any blank area on the 2D drawings to open drawing property menu. Assign the name of this 2D drawing as shown below. User can also adjust drawing properties such as views, dimension, marks, objects in the drawing property menu. Click Modify > Apply > OK to finish.

| 1 1 | 000 | | | Tekla Structures - CNTe | REStructures Model P.C.C. DEMO MODE | L - 16 (HT) | | | A North N | s = 0 > |
|------------|--|---|--|-----------------------------------|--|--------------------|-----------------------|-----------------------------------|-------------------------------|--|
| - R | Document Concentration Concentration | 965 DMENSIONIN F <u>E</u> LCore F G Xiove G Remote O Propertie | VEW III creation IIII creation III creation <l< th=""><th>:</th><th></th><th>Jan 7 Forgest 4</th><th>🔀 Wed mark</th><th>C Sector mark 🖾 O Deter mark O</th><th>Curringer aut</th><th>- 0 - 0 - 0 - 0 - 0 - 0 - 0 - 0 - 0 - 0</th></l<> | : | | Jan 7 Forgest 4 | 🔀 Wed mark | C Sector mark 🖾 O Deter mark O | Curringer aut | - 0 - 0 - 0 - 0 - 0 - 0 - 0 - 0 - 0 - 0 |
| | | | | | | | | | | |
| | | | 6 | | | | 9 ~ | | | 33 |
| | | | | | | | Trapica of minal | | | 0 |
| | | | | | | | And the second | | | : |
| | | | | | | | Contract of the local | | | |
| | | | | | | | | _ | | _ |
| | | | | General analy | serve drawing properties | | | | | |
| | | | | See 5 | sas menseo | | | Spear | standard | |
| | | | | ⊠Name \$200 ⊡Tide ti \$000 | l Typical Floor Pain I Typical Floor Pain | | | | | |
| | | | | Pl fide 2 | | | | | | |
| | | | | Settings | | | | | | |
| | | | | 🕑 Uleda | ralled object level settings in his | 10 | | | Edit settings. | |
| | | | | | Lyon. | E | View. | E I | Detail view_ | |
| | | | | 2 | Section view | | | | | |
| | | | | Dimensions TT - 2 | - | 1.1011 | | | | |
| | | | | Marks | Contention. | | Unerskierty | | | |
| 100 | | | ILXAOD | | Put nark. | | Bolt mark. | 12 | Neighbor part mark. | |
| | and a state of the state of the | a series a series | | 8 | Surface treatment mark. | - 2 2 | Weld mark_ | 8 | Reinforcement marks | |

E General arrangement drawing properties

| Save | Load standard |
|------------|--|
| - | |
| | |
| Name: | S002 Typical Floor Plan |
| | |
| ✓ Title 1: | S002 Typical Floor Plan |
| _ | |
| ✓ Title 2: | |
| _ | |
| ✓ Title 3: | |
| Continues | |
| Settings | |
| | Use detailed object level settings O No. O Ves |
| \sim | Ose detailed object level settings O NO O les |
| | |
| Views — | |

The name assigned in the drawing property menu can be found in the document manager after the user leaves this drawing close drawing mode by pressing the button as shown below. After drawing mode is close, Tekla would switch from drawing mode back to 3D modelling mode.



5.2 Inserting Views to Drawings

In 3D modelling mode, one the Drawings & Report tab, click "Document Manager" to choose the drawings which needed to be edited. Double click the name of the drawing to switch from 3d modelling mode to drawing mode. Please note users could only delete unwanted drawings in Document Manager when Tekla is in 3D modelling mode. Right-click the name of the drawing in document manager to delete unwanted drawings.

| 700 | | rekia su uctures - v | | MODEL DEMO_MODEL | |
|-----------------------------|---|----------------------|--------------------------|--|-----------|
| STEEL CONCRETE EDIT | VIEW DRAWINGS & REPORTS | MANAGE ANAL | rsis & Design | TRIMBLE CONNECT | BRIDGES |
| ' D Q | Perform numbering | Numbering settings | · 🗐 | Gr DIM | ases |
| Document Drawing | Create | Change number | | 4 4 | sh check |
| manager | | | Reports | Organitier Co | |
| Document manager | | | | | |
| 3 | Search | q / | % 0 | ₿. <u>1</u> ⊗ | |
| All documents | Name 🔺 | Changes | Created | Document type | C Extensi |
| All files | D002 Demonlition Plan | | 07.05.2019 | GaDrawingDocument | |
| All drawings | D004 Detail for Demolition Works | | 17.05.2019 | GaDrawingDocument | |
| Single-part drawings | E001 ELS Layout Plan | 26.05.2019 | | GaDrawingDocument | |
| Assembly drawings | P001 General Notes for Foundation | | 23.04.2019 | GaDrawingDocument | |
| Cast unit drawings | P002 Piling Layout Plan | | 17.05.2019 07.05.2019 | GaDrawingDocument GaDrawingDocument | |
| Gå drawings | P003 Piling Section | | | | |
| Ge uranniya | P003 Piling Section | | 17.05.2019 | GaDrawingDocument | |
| Up-to-date drawings | P004 Bored Pile Loading Schedule | | 06.05.2019 | GaDrawingDocument | |
| Out of date drawings | P005 H-Pile Loading Schedule | | 07.05.2019 | GaDrawingDocument | |
| Obsolete drawings | P006 Column Wall Loading Plan | | 09.05.2019 | GaDrawingDocument | |
| Issued drawings | P006 Column Wall Loading Schedule | | 17.05.2019 | GaDrawingDocument | |
| Issued but changed drawings | P007 Loading Intensity Plans | | 15.05.2019 | GaDrawingDocument | |
| Locked drawings | P008 Monitoring Plan | | 03.05.2019 | GaDrawingDocument | |
| Frozen drawings | P009 Pile Cap RC Detail (Cap for Socket H Pile) | | 15.05.2019 | CastUnitDrawingDocument | |
| Ready for issuing drawings | P009 Pile Cap Reforcement Layout Plan | | 15.05.2019 | GaDrawingDocument | |

In drawing mode, one the view tab, pick Area in Model View and then choose the model view which is required to be put into the 2D drawings. Double click a blank area in drawing to adjust drawing property of the whole drawing, double click the imported view to adjust view property of the specific view. Users may use phase manger to categorise Tekla elements to a different phase and set rules in the filter in the view property menu to control whether different elements are being shown in drawings. In Tekla settings in view property will override settings in drawing property.



5.3 Creating Text and 2D Typical Details to Drawings

After putting views from 3D models to drawings, users can create text. In drawing mode, on the annotation tab, click text to inset text on drawings.



2D typical details could also be added in Tekla. Users may either create native Tekla 2d objects in drawings by using the buttons on the drawing tab as shown below or insert 2D dwg / dng files to Tekla directly. 2D drawing pieces could be stored in Tekla built-in 2D Library such that users could reuse those details in other drawings. Users can also import 2D .dwg files to the 2D library directly. The link below provides all necessary information about 2D Library in Tekla,



https://teklastructures.support.tekla.com/2017/en/dra_details_in_drawing_2d_library

5.4 Adding Dimensions and Marks to Drawings

Dimensions are vital in construction drawings. After putting views from 3D models to drawings, users may specify dimensions to Tekla objects. This can be done by simply using the buttons on the dimension tab in drawing mode.



In Tekla beam, columns, slabs and panels are called parts and users could add marks to parts in drawings. Users can create and control part marks in the drawing property menu and view the property menu. Besides, users could also control marks of individual part by right click at specifying part in drawing mode. One part could only be annotated by one mark on drawings, if users need to annotate additional information of specifying a part, users need to use associative notes by clicking the "note" button under the annotation tab in drawing mode.



5.5 Creating Title Blocks and Schedules to Drawings

In Tekla, table-like objects (such as schedules, tables and title block or drawing frame) are created by using template editor to list out information.

To create Title Block in Tekla, please refer to this official step-by-step video.

https://teklastructures.support.tekla.com/video-tutorials/en/import-dwg-template-editortitle-blocks

| | | | 9 2 2 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 |
|--|---|---|---|
| | | | |
| Sorting and drawin | ng order | | 111 Mart 1017 1017 1017 1017 |
| 🕀 🖿 Template: | CIC_Titleblock.tpl | | |
| | | | Purpose of issue (stamp3) |
| | | | Purpose of issue (stamp2) |
| | | | Purpose of issue |
| | | | (stamp1) |
| | | | (stamp1) |
| Devidence Device | | | (stamp1) 10 acress 400 |
| Preview Pane | Value | | (stamp1) |
| Preview Pane Property | Value | ~ | (stamp1) in second, select second second s |
| Preview Pane Property Type Width | Value Graphical 100 on | | (stamp1) In seven alle |
| Preview Pane Property Type Width May Height | Value Graphical 100.00 744.00 | | (stamp1) III. constrained III. Constrained IIIII. Constrained III. Constrained |
| Preview Pane — Property | Value Graphical 100.00 784.00 540.00 | A | (stamp1) In server, see In s |
| Preview Pane Property Type Width Max, Height Height Min, Columns | Value Graphical 100.00 784.00 560.00 1 | ^ | (stamp 1) In seven Alls Seven Alls Seven State Seven |
| Preview Pane Property Type Width Max, Height Height Min, Columns Max, Columns | Value Graphical 100.00 784.00 560.00 1 | | (stamp 1) |
| Preview Pane Property Type Width Max, Height Height Min, Columns Max, Columns Max, Columns | Value Graphical 100.00 784.00 580.00 1 1 1 Even | | (stamp 1) III. convert. All B III. convert. All B IIII. convert. All B III. convert. All |
| Preview Pane Property Type Width Max, Height Height Min, Columns Max, Columns Fill Policy Fill Policy | Value Graphical 100.00 784.00 560.00 1 1 Even Horizontal | | (stamp 1) In server, Alle In server, A |
| Preview Pane Property Type Width Max, Height Height Min, Columns Max, Columns Fill Policy Fill Drir. Staf from corper | Value Graphical 100.00 784.00 560.00 1 1 Even Horizontal Too left | | (stamp 1) |
| Preview Pane Property Type Width Max, Height Height Height Max, Columns Fill Policy Fill Dir. Start from corner Left Marrin | Value Graphical 100.00 784.00 560.00 1 1 1 Even Horizontal Top left 0.00 | | (stamp 1) III. convert. AND III. convert. AND IIII. convert. AND III. convert. AND I |

Users could also tabulate information stored in Tekla objects inside the template editor. This can be done by using the Value Field button in the templated editor as shown below.

Value Fields in Tekla could recognise objects captured inside views inside the same drawing. Value Fields are needed to the put inside "Row" (the blue box) in the template editor. Users could also use a formula to calculate information in Tekla objects and tabulate the answer in Template Editor. Please refer to the link below for more information :

https://teklastructures.support.tekla.com/2018/en/rel_2018_template_editor_improvements

| 다. 프 프 이 프 프 I | ×6% • * つ C / | | 占 T | | 88 |
|--|---|---|--|---|--------------------|
| Sorting and | drawing order (Mol_10 LineOhar_189 LineOhar_191 LineOhar_191 LineOhar_192 | > | | | |
| | Content Content | * | BORED PILE MARK | BORED PILE CAP THICKNESS (FOR REFERENCE ONLY) | BORED P DIAMETE |
| | Line count 1 | | | (m) | (m) |
| Proview Pane Property Name Hide in outp X Y Formula Max lines Datatype | Usit type: I was Output 0 as an empty string | When room and an analysis of the second | CONTRACTION OF CONTRACT OF CONTRACT. | PILECAPT | BP_DIA |
| Meaning Zero as emp Justify | a Justity: Center) Angle: 0.00 deg | | | | |
| Andle | 1 Set as default for new value fields | OK Apply Cancel | | | |
| Ready | | | Angle: 0.00 1 value field(s) | | |

Users may refer to drawing P004 in the sample model. The Bore Pile Loading Schedule provided an example of how this could be achieved by using Tekla.

UDA was added to the template editor before value field was added to the template editor, please refer to the link below for information.

https://teklastructures.support.tekla.com/2019/en/rep_adding_userdefined_attributes_to_tpl ed

| 1 = 12 × | G-G ● ► | ວເ / | 7/ -0 | r e 🖙 😨 | 201 | | -8 | T 📾 e 🛒 🖓 | 068 | a a |
|---|---|--|---|--|---|--|--|--|--|--|
| - 平 左 | 118 | | | - | | | | | | |
| Corting and draw | (ng order | | 6 | 1 - | | | | | | |
| E- In Templato | (FND) Sored Pile Loa | ding Schedule (1 of 2).tpl | | | | | | | | |
| E E PART | er | | | - | | | | | | |
| 11 | UME field | | | 100 | - | | | | | |
| 1 | neColor_0 | Value Field Properties | | × | 4 | | BORED PILE C THICKNESS (FO | OR BORED P | BORED P | PILE |
| 11 | NeOFAIC/11 | Content Formula: Gertalue ("USERDERINED CIC PILE_BP_CTHK") | | | ORE | PHE | | | ILE EFFECT | IVE ROCK |
| / LeeOAc.2 // LeeOAc.3 // LeeOAc.3 // LeeOAc.6 // LeeOAc.6 // LeeOAc.6 | | Attribute., Formula | | | MAF | RKR | REFERENCE OF | NLY) DIAMET | ER SHAFT | ED DIAI |
| | | | | | | | | DIAMETE | | |
| | | Name PLLCAPT | | | | | (m) | (m) | (m) | |
| | | Data type: Number with doc mat: +) Order: Accending + | | | NAME_ | field | BILEGAPTO | 8P_DIA | BP_ESDIA | BP_ |
| /1 | nirOrAic_9 | P Output 0 as as emoty string | | | | | | | | |
| Proview Pane | ister i | T Hide in output | Wentrows an | e combined alors | 1 | | | | | |
| Name | PRECAPT | Meaning: Length | C Sum values | across all tows | | | | | | |
| inde in output | Sabe | ues 💷 | C Son values | within one row | | | | | | |
| × Y | 0.781000844 | Decimals 2 | Free attributes. | .] | | | | | | |
| Max Eren | GetValue(TUSERD) 1 | Layout | | | | | | | | |
| Datatype | Number with deci | Foot Add 0.6 teoght 10 OARG | | | | | | | | |
| Nicolang Zero as empty | Tote | | | | 1 | | | | | |
| histily | Seft. | | 1.7260 113V2 | an Einannar | | | | | | |
| Takis Tempus Tida Vina 1 m 1 2 X | Fatter - Du Jilme et wert Options Help Ru Ru Options Help | internet and the second second second | | ing foliedaire i re | 12.00 | | 4 | Taseac | 0688 | - e × |
| lana herepak r Idt Vew } ■ Ⅲ X k = Ⅲ K | inter-Dational and Option Inter Colors Inter- Î Î Â | ind sectary difficult on restar, in norm | oerguesia th Or Bowd Pie Loc ⁹ ∕ ₽ O ¤ ● ■ 1 | ng ichodau it e 1 m 🗠 gg | 12.00 [b] | | 14 | T≖s⊰⊊ | 0000 | × |
| | Fatter - D Mindere ment Options Help Po The O A Î T A | 94 maan 200 maa ah a | rampuston NO: Bond Pie Loc → ✓ ♥ ○ □ ● ■ 1 ► | ing Scheden († c | 12.00 [b] | | 4 | | 0000 | |
| Takin Tempoto Takin Yosu Takin Yosu Tak | Fatter CX, Direc et auert October Fatter I f A King order P (SSDA P (SPDA | ied industrialities enned in an dener | ormjust NO lost Pa Loc ² ∕ ♥ O □ ● = 1 P | ing Scheden () c | | | 占 B | T 교 역 곳 및 ORED PILE L | CADING SCH | EDULE (1 |
| Contractions Total Verse Contractions Con | Fattor - DL, Jähner ei aust Orstone Fatty The Call Call I and Fig order P 1950A P 2950A P 2950A P 2950A P 2950A P 2950A | Ned Status (1999) and state of the State of Stat | company, filo, lovel Pia Love 2 / P O D O O O O O O 1 2 2 2 2 2 2 2 2 2 2 2 2 2 | ng Torestee it o I so the juicit | 12.00 | (W) | 百 日 2=W-0.3-(X)-(Y) | T 도 은 공격 다 ORED PILE L (AB)=(AA)-(Z) | oeea OADING SCH (Y) | EDULE (1 |
| Total Tempore is Table Yow To Mill X and To Mill X and To Mill X and To Mill X and Total X | Tattor - DL, Janne el aurol Orstonio Taty To Tat Orstonio I 1 A Pisson Pi | 2 C | ergunt ¹ 0 Ioni Pa Loc 2 ∕ ₽ 0 □ 0 ■ 1 1 8 | AA) | | | E B Z≠₩-03(X⊢(Y) TENTATIVE | 다 : : : : : : : : : : : : : : : : : : | C & A A | EDULE (1 (a) |
| The Impose a List You To M I A a List Fill A List A List | Fatter - D | 2 <u>2 2</u> | engues TO lost Palac C P O D C T (| ag icedae i c ag Be ig: (AA) EE i EixEi | TEN | (W) ITATIVE CKHEAD | В Z=W+0.3-(Х+(Y) TENTATIVE FOUNDING | T == = sd ⊂ ORED PILE L (AB)=(AA)-(Z) TENTATIVE PILE | O & A A | EDULE (1 |
| Constant for a particular of the second seco | Fatter CS, Chine et and Costanti Lidge Costanti Costanti Lidge Costanti Costanti Costanti Costanti Pristova Prist | ind fraction with the moment of a service of the se | Completel, FIG: Bond File Loo P P O D • = 1 P | а Селан (с а 19 19) (с АА) Резерен | TEN ROC X | (W) ITATIVE CKHEAD EVEL | E Z=W+03-(X)-(Y) TENTATIVE FOUNDING LEVEL | T I I I I I I I I I I I I I I I I I I I | O & A A | EDULE (1 (a) SELF-WEIGH OF BORED PI (SUBMERGED (SWEP) |
| Constant for any other of the second | Factor - C. Three et and former - C. Three et al. (1997) - C. Three et al. (1997) - C. (19 | Vel Industri Ultilian mineccia, si ricent 2. C / / / / / / / / / / / / / / / / / / | Samples, PO: Boost Pia Loc Complexit, PO: Boost Pia Loc () () () () () () () () () () | а Сенан на а Сен | TEN ROC X | (W) ITATIVE CKHEAD EVEL | B Z=W+03-(X)-(Y) TENTATIVE FOUNDING LEVEL | T ISE IS K CB ORED PILE L (AB)=(AA)-(Z) TENTATIVE PILE LENGTH | C C C C C C C C C C C C C C C C C C C | EDULE (1 (a) SELF-WEIGH OF BORED PI (SUBMERGEI (SWP) |
| | Fattor - C. Chine en march Contact line: Contact - C. Chine en Contact - C. Chine en Contact - C. Chine en Contact - C. Chine en P. SSOA P. | Net Structure UNIT Deveronment as an offerer 2 C / / / / / / / / / / / / / / / / / / | Computer, FVC Bond Pia Loc Computer, FVC Bond Pia Loc Computer Computer Computer Black (CDPP) Control Formulae | AA) ce : e.e. | | (W) ITATIVE CKHEAD EVEL nPD) | B Z=W+0.3-(X)-(Y) TENTATIVE FOUNDING LEVEL (mPD) | T SE & K CH ORED PILE L (AB)=(AA)-(Z) TENTATIVE PILE LENGTH (m) | OADING SCH (Y) EFFECTIVE ROCK SOCKET LENGTH (m) | EDULE (1 (a) SELF-WEIGH OF BORE DI (SUBMERGEI (SWP) (KN) |
| | Tentor On The energy of the en | No second and a second as a No Properties enfort decrements (PB, Text) > 0.3 Get 6 end corrula; CBP enfort decrements (PB, Text) > 0.3 Get 6 end corrula; CBP matrix - / Text) > 0.3 Get 6 end corrula; CBP matrix - / Text) > 0.3 Get 6 end corrula; CBP | SettloutDSP GetheldSvm.det | AA) | TEN ROO × | (W) ITATIVE CKHEAD EVEL nPD) TRHL | B Z=W+0.3-(X)-(Y) TENTATIVE FOUNDING LEVEL (mPD) BP-T-C | T I RE IS KITA ORED PILE L (AB)=(AA)-(Z) TENTATIVE PILE LENGTH (m) BP_TPL | CADING SCH (Y) EFFECTIVE ROCK SOCKET LENGTH (m) BP_ERSL | EDULE (1 (a) SELF-WEIGH OF BORED PI (SUBMERGE (SUBMERGE (SWP) (KN) BP_SWP |
| tests temporal tests temporal tests temporal tests temporal tests temporal tests temporal tests | Table Control ling The Contro | Ad Properties Properties Projections Proj | Parguest, FO: Band Pia Loo P P O D • • 1 P SallouTDEP, Gefneld Sum Jer | 19 14 15 15 1 (AA) EE 1 E 161 | TEN | (W) ITATIVE CKHEAD EVEL mPD) TRHL | B Z=W+0.3-(X)-(Y) TENTATIVE FOUNDING LEVEL (mPD) (B ^P -T ^L D | T I I I I I I I I I I I I I I I I I I I | C & A DADING SCH (Y) EFFECTIVE ROCK SOCKET LENGTH (m) BP_ERSL | EDULE (1 (a) SELF-WEIGH OF BORED PI (SUBMERGE (SWP) (KN) BP_SWP |
| tests temporal tests temporal tests temporal tests temporal tests temporal tests temporal tests | Tame D. Janese med Oracion (etc.) The Carlos (etc | No Properties | SPELDOUTDEP-, Gerineld Surmulari Outer - Jacob | | TEN | (W) ITATIVE CKHEAD EVEL mPD) TRHL | B z=₩+03-(X)+(Y) TENTATIVE FOUNDING LEVEL (mPD) BP-TE | T IS & K CH ORED PILE L (AB)=(AA)-(Z) TENTATIVE PILE LENGTH (m) BP_TPL | C & A A DADING SCH (Y) EFFECTIVE ROCK SOCKET LENGTH (m) BP_ERSL | EDULE (1 (a) SELF-WEIGH OF BORED PI (SUBMERGE (SUMP (KN) BP_SWP |
| the intervence the intervencee the intervencee the in | Faith Control line Reg order P State Contrel Reg order P State Control line Reg order P State | Net industri diffit annoneccia en connec 2 C / / / / / / / / / / / / / / / / / / | Sergiumi, PCA Bont Pia Loc 2 / P O D O I I 8 88100-00872-SerbekSvim.lec Ocere: [P000 | na (credus i i c | TEN TEN RO(| (W) ITATIVE CKHEAD EVEL mPD) TRHL | B Z=W+0.3(XHY) TENTATIVE FOUNDING LEVEL (mPD) @P_TE ^L D | T SE & K CB ORED PILE L (AB)=(AA)-(Z) TENTATIVE PILE LENGTH (m) BP_TPL | O @ @ @ OADING SCH (Y) EFFECTIVE ROCK SOCKET LENGTH (m) BP_ERSL | EDULE (1 (a) SELF-WEIGH OF BORED PI (SUBMERCE (SWP) (KN) BP_SWP |
| Construction | Later Control line ment Control line Control line Contr | No Properties | Company INC Root Pa Loc Company INC Root Pa Loc Company RELIQUIDEP's Generative muter Outer [Acco - We - We | AA) EE I EVEN rang = en roos are come or som some come | | (W) ITATIVE CKHEAD EVEL nPD) TRHL | B Z=W-0.3<(X)=(Y) TENTATIVE FOUNDING LEVEL (mPD) BP_TEL D | T SE & K. C. | OADING SCH (Y) EFFECTIVE ROCK SOCKET LENGTH (m) BP_ERSL | EDULE (1 (a) SELF-WEIGH OF BORED PI (SUBMERGE (SWP) (KN) BP_SWP |
| Control formula for a first Visual Control for a firs | Table Control ling The Contro | All Properties | Anny Lee, This Bank Pie Lee P P O D C C C C C P P P P P P P P P P P P P | AA) EE I EVEL AAA) EE I EVEL AAA) EE I EVEL AAA) EE I EVEL AAA) | TEN ROOK | (W) ITATIVE CKHEAD EVEL nPD) TRHL | B Z=W+0.34(X)+(Y) TENTATIVE FOUNDING LEVEL (mPD) (mPD) (mPD) | T ISS IS K CB ORED PILE L (AB)=(AA)-(Z) TENTATIVE PILE LENGTH (m) BP_TPL | O & A OADING SCH (Y) EFFECTIVE ROCK SOCKET LENGTH (m) BP_ERSL | IEDULE (1 (a) SELF-WEIGH OF BORED (1 (SUBMERGE (SWP) (KN) BP_SWP |
| A many large part of the second | Tame Distance line and Distance line To The Distance line and the Distance line and the Distance line proba- pro | No fragencia No fragencia Port (1997) No fragencia Port (1997) No fragencia Port (1997) Port (1997) P | SPELDOUTDEP-, GetheldSymular Oger (Jacob | 10 10 | TEN ROQ × | (W) (TATIVE CKHEAD EVEL nPD) TRHL | E z=₩+03-(X)+(Y) TENTATIVE FOUNDING LEVEL (mPD) மூ-ரு.்ற | T ISE E ≤ CH ORED PILE L (AB)=(AA)-(Z) TENTATIVE PILE LENGTH (m) BP_TPL | OADING SCH (Y) EFFECTIVE ROCK SOCKET LENGTH (m) BP_ERSL | EDULE (1 (a) self-weich of Bored Pi (SUMBERGE (SWP) (KN) BP_SWP |
| A second large larg | Faither Charlows Hale The Control Hale Reg older PLSDA | Net inclusi Unit an interesta a services 2 C 2 3 M Properties enforthermode (PB, Test) - 0.3 Get incloserula (PB enforthermode (PB, T | RELIGUIDEP? GetheldSum der Oder [Aussigner] Coder [Aussigner] Street Street Sum der Street Street Street Sum der Street Street Str | AA) EE I EVEL AAA) EE I EVEL AAA) EE I EVEL AAA | TEN ROC X Steed afroes courtou | (W) ATATIVE CKHEAD EVEL nPD) TRHL | B Z=W+03(XHY) TENTATIVE FOUNDING LEVEL (mPD) BP-TC D | T ISE & K ICE ORED PILE L (AB)=(AA)-(Z) TENTATIVE PILE LENGTH (m) BP_TPL | C & A A | EDULE (1 (a) SELF-WEIGH OF BORED PI (SUMMERCE) (SUMMERCE) (SWP), (KN) BP_SWP |
| Tennes Terminal Sectors Terminal Terminal Sectors Terminal | Tartino Control Inter Control Control Inter Control Control Inter Control Control Inter Participation Control Control Participation Participatio Part | di Properties PC // / / / / / / / / / / / / / / / / / | BELLOUTDEPT-GetheldSummler | ang Scheduler (C B B B) (A) (A,A) EE I EV.E) en rous are come on valuers access on | TEM TEN X X | (W) ITATIVE CKHEAD EVEL nPD) TRHL | B Z=W-0.3(X)-(Y) TENTATIVE FOUNDING LEVEL (mPD) BP-TEL D | T See See Control of the second secon | OADING SCH (Y) EFFECTIVE ROCK SOCKET LENGTH (m) BP_ERSL | EDULE (1 (a) SELF-WEIGH OF BORED PI (SUBMERGEE (SWP) (kN) BP_SWP |
| Tester Vinie T | Tamer Control ling To a control | All Properties PC All Properties All Proper | SELLOUTDEP's Gerheid Sum Jan SELLOUTDEP's GERMANNES SELLOUTDEP'S SELLOUTDEP'S GERMANNES SELLOUTDEP'S SELLOUTDEP'S SELLOUTDEP'S S | AA) FE I EVEL AAA) FE I EVEL en roke an como on taxe makes an induce como on taxe makes | TELO TECO X V | (W) ITATIVE CXHEAD EVEL nPD) TRHL | B Z=W-0.3-(X)-(Y) TENTATIVE FOUNDING LEVEL (mPD) (mPD) | T SS S K Ca ORED PILE L (AB)=(AA)-(Z) TENTATIVE PILE LENGTH (m) BP_TPL | OADING SCH (Y) EFFECTIVE ROCK SOCKET LENGTH (m) BP_ERSL | EDULE (1 (a) SELF-WEIGH OF BORE DP (SUBMERGEL (SWP) (KN) BP_SWP |
| A second large larg | Tame Distance line To an | All Properties All Propertie | SPELDOUTDEP-, Getineld Formular Outer Jose Free Free | AA) EE LEVEL AAA) EE LEVEL Marg = en roos se conc on takes writers writers writers | TEN RO X Seed | (W) (TATIVE CKHEAD EVEL nPD) TRHL | اللہ اللہ اللہ اللہ اللہ اللہ اللہ الل | T ISE E ⊻ CH ORED PILE L (AB)=(AA)-(Z) TENTATIVE PILE LENGTH (m) BP_TPL | OADING SCH (Y) EFFECTIVE ROCK SOCKET LENGTH (m) BP_ERSL | EDULE (1 (a) self-weich of Bored Pi (SWP) (KN) BP_SWP |
| Initial Temporal Initial Sectors Initia Sectors Initial Sectors I | Finite Control line The Control line Registress of the Control Registress of the Control Registres | In Properties If Properties If Properties If Properties If Properties If Properties If Promote | RELIDUITORY Getheldform.det 0.000 D007 RELIDUITORY Getheldform.det 0.000 D007 Yes Proc | AA) EE I EVEL AAA) EE I EVEL AAA) EE I EVEL AAA AAAAAAAAAAAAAAAAAAAAAAAAAAAAAAA | TEN RO X Sind si ross on ros | (W) ATATIVE CKHEAD EVEL nPD) TRHL | B Z=W+03(XHY) TENTATIVE FOUNDING LEVEL (mPD) BP_TC | T ISE & K ICE ORED PILE L (AB)=(AA)-(Z) TENTATIVE PILE LENGTH (m) BP_TPL | C & A A | EDULE ((a) SELF-WEIGI OF BORED P (SUBMERGE (SWP) (kN) BP_SWP |

6 Exporting Tekla Models as Deliverables

6.1 Exporting 3D models as ifc

IFC model could be exported by Tekla by simply clicking Export > IFC in the File menu as shown below.



6.2 Exporting 2D drawings as pdf or dwg

2D drawings could be exported by right click selected drawings in Document Manager in 3D modelling mode as shown below:

| | Search | Q | 1 | T _h | | 4 <u>1</u> © | |
|----------------------------|-----------------------------------|--|---------------|----------------|---------------------------|----------------------|--|
| All documents | Name 🔺 | (| hanges | | Created | Document type | |
| All files | D001 GENERAL NOTES FOR DEMOLITION | | | | 17.05.2019 | GaDrawingDocument | |
| All drawings | D002 DEMONITION PLAN EXISTING G/F | | | | 31.05.2019 | GaDrawingDocument | |
| Single-part drawings | E001 ELS LAYOUT PLAN | | | | 26.05.2019 | GaDrawingDocument | |
| Assembly drawings | D002 DEMOLITION PLAN | | | | 31.05.2019 | GaDrawingDocument | |
| Cast unit drawings | HODT HOARDING LAYOUT PLAN | | | 07.05.20 | | GaDrawingDocument | |
| Multidrawings | P001 GENERAL NOTES FOR FOUNDATION | | | | 23.04.2019 GaDrawingDoo | | |
| ow drawings | P002 PILING LAYOUT PLAN | | | | 17.05.2019 GaDrawingDocur | | |
| Up-to-date drawings | P003 PILING SECTION A & SECTION B | | | | 17.05.2019 | GaDrawingDocument | |
| Out of date drawings | P004 PILIING SECTION C | Properties User-defined attributes Revision Update marks | Ait+Ent | ter | 07.05.2019 | GaDrawingDocument | |
| Obsolete drawings | P005 COLUMN / WALL LOAD | | tes Alt+U | | 09.05.2019 | GaDrawingDocument | |
| ssued drawings | P006 COLUMN / WALL LOAD | | Ctrl+R | Ctrl+R | 17.05.2019 | GaDrawingDocument | |
| ssued but changed drawings | P007 LOADING INTENSITY PL | | C1-10-0 | | 15.05.2019 | GaDrawingDocument | |
| Locked drawings | POOB PILE LOAD SCHEDULE | Recreate | Shift+R | | 06.05.2019 | GaDrawingDocument | |
| Frozen drawings | P009 MONITORING PLAN | Export | Ctrl+E | -1 | 03.05.2019 | GaDrawingDocument | |
| Ready for issuing drawings | P010 PILE CAP REINFORCEME | Copy rows to Clipbo | pboard Ctrl+C | | 15.05.2019 | CastUnitDrawingDocum | |
| | P010A PILE CAP REINFORCEM | Select all | Ctrl+A | | 15.05.2019 | GaDrawingDocument | |
| superstructure | PD11 COLUMN AND WALL ST | Copy to new sheet | | | 16.05.2019 | GaDrawingDocument | |
| | P012 (TB1) RC Detail | Create multidrawing | 2 | | 20.05.2019 | GaDrawingDocument | |
| | P012 TIE BEAM DETAILS & SC | Lock | , , , | | 17.05.2019 | GaDrawingDocument | |
| | S002 TYP Floor Framming | Freeze | | | 23.04.2019 | GaDrawingDocument | |
| | SOOS BEAM RC DETAIL | keady for issuing Issue | | | 24.05.2019 | GaDrawingDocument | |
| | | Manual category | | | | | |
| | | 1 Delete | Del | | | | |



Feedback Form

CIC BIM User Guide for Preparation of Statutory Plan Submissions Tekla December 2020

To improve future editions of this publication, we would be grateful to have your comments.

| 1. | As a whole, I feel that the publication is: | Strongly | Agree | Neutral | Disagree | Strongly | | |
|---|---|-------------|-----------|-----------------|----------|----------|--|--|
| | | Agree | | | | Disagree | | |
| | Informative | | | | | | | |
| | Comprehensive | | | | | | | |
| | Useful | | | | | | | |
| | Practical | | | | | | | |
| 2. | Does the publication enable you to understand | Yes | | No No | | Comment | | |
| | more about the subject? | | | | | | | |
| З. | Have you made reference to the publication in | Quite Often | | Sometimes Never | | Never | | |
| | your work? | | | | | | | |
| 4. | To what extent the publication benefits you? | Strongly | Agree | Neutral | Disagree | Strongly | | |
| | | Agree | | | | Disagree | | |
| | Supply chain Information/data integrity | | | | | | | |
| | Work efficiency | | | | | | | |
| | Project Collaborations | | | | | | | |
| 5. | Overall, how would you rate our publication? | Excellent | Very Good | Satisfactory | Fair | Poor | | |
| | | | | | | | | |
| | | | | | | | | |
| 6. Other comments and suggestions, please specify (use separate sheets if necessary). | | | | | | | | |
| Personal Particulars (optional):* | | | | | | | | |
| Name: Mr. / Mrs./ Ms./ Dr./ Prof./ Ar. / Ir / Sr ^ | | | | | | | | |
| Company: | | | | | | | | |
| Tel: | | | | | | | | |
| Address: | | | | | | | | |
| E-mail: | | | | | | | | |
| | 1011. | | | | | | | |

(Please put a " \checkmark " in the appropriate box.)

- * The personal data in this form will be used only for this survey. Your data will be kept confidential and dealt with only by the Construction Industry Council.
- ^ Circle as appropriate.

Please return the feedback form to: CIC Secretariat – BIM E-mail: bim@cic.hk; Address: 38/F, COS Center, 56 Tsun Yip Street, Kwun Tong, Hong Kong Fax No.: (852) 2100 9090

Construction Industry Council

Address : 38/F, COS Centre 56 Tsun Yip Street Kwun Tong, Kowloon Tel : (852) 2100 9000 Fax : (852) 2100 9090 Email : enquiry@cic.hk Website : www.cic.hk

©2020 Construction Industry Council